

We have some firmware that supports the 16F87xA parts. This is not directly supported by Microchip, but has been tested and deemed functional. By using this firmware you are agreeing that it comes "as is," and technical support is not available. To get this firmware:

- 1) FTP://devtools:devtools@ftp.microchip.com
- 2) User name: devtools
- 3) Password: needtools
- 4) Click on the "MPLAB Classic" to navigate to the ICD24001.OBJ file
- 5) After upgrading MPLAB ICD firmware with this file, the firmware will detect whether you are using an "A" part or a "non-A" part by reading the device ID in the target. An error message is currently being generated when you load this new firmware. Ignore it.