



US007139157B2

(12) **United States Patent**
Taylor

(10) **Patent No.:** **US 7,139,157 B2**
(45) **Date of Patent:** **Nov. 21, 2006**

(54) **SYSTEM AND METHOD FOR PROTECTING A LOAD FROM A VOLTAGE SOURCE**

(75) Inventor: **John P. Taylor**, San Diego, CA (US)

(73) Assignee: **Kyocera Wireless Corp.**, San Diego, CA (US)

(*) Notice: Subject to any disclaimer, the term of this patent is extended or adjusted under 35 U.S.C. 154(b) by 197 days.

(21) Appl. No.: **10/903,984**

(22) Filed: **Jul. 30, 2004**

(65) **Prior Publication Data**

US 2006/0023381 A1 Feb. 2, 2006

(51) **Int. Cl.**
H02H 3/20 (2006.01)

(52) **U.S. Cl.** **361/84**; 361/91.2; 361/91.7; 361/111

(58) **Field of Classification Search** 361/91.7, 361/91.2, 91.1, 90, 111, 82, 84
See application file for complete search history.

(56) **References Cited**

U.S. PATENT DOCUMENTS

4,716,489 A	12/1987	Imamura et al.	361/91.2
4,763,184 A *	8/1988	Krieger et al.	257/362
4,814,687 A	3/1989	Walker	323/275
4,890,020 A	12/1989	Bird	227/113
4,893,158 A	1/1990	Mihara et al.	257/341
4,949,211 A	8/1990	Edwards	361/18
4,955,069 A	9/1990	Ionescu	388/811
5,012,381 A	4/1991	Elliott et al.	361/184
5,023,692 A *	6/1991	Wodarczyk et al.	257/370
5,111,353 A	5/1992	Kotowski et al.	361/91.1

5,159,515 A	10/1992	Fishbein	361/18
5,325,258 A	6/1994	Choi et al.	361/87
5,488,533 A	1/1996	Cassidy	361/93.1
5,546,264 A *	8/1996	Williamson et al.	361/84
5,585,991 A *	12/1996	Williams	361/30
5,592,353 A	1/1997	Shinohara et al.	
5,666,254 A	9/1997	Thomas et al.	361/8
5,684,663 A	11/1997	Mitter	361/106
5,714,869 A	2/1998	Tamechika et al.	320/101
5,742,463 A	4/1998	Harris	361/88
6,049,447 A	4/2000	Roesch et al.	361/58
6,054,738 A	4/2000	Sander et al.	257/341
6,067,219 A	5/2000	Armstrong et al.	361/101
6,154,081 A	11/2000	Pakkala et al.	327/309
6,304,422 B1	10/2001	Sander et al.	361/84
6,606,227 B1 *	8/2003	Rapsinski et al.	361/86
6,678,183 B1 *	1/2004	Creger et al.	363/146
6,707,654 B1	3/2004	Ito et al.	361/58
6,791,296 B1 *	9/2004	Chu et al.	320/114
6,992,467 B1 *	1/2006	Fey	323/266

OTHER PUBLICATIONS

Paul Horowitz and Winfield Hill, The Art of Electronics. 1989. Press Syndicate of the University of Cambridge, 2nd Edition. pp. 48-51.*

* cited by examiner

Primary Examiner—Brian Sircus
Assistant Examiner—Terrence Willoughby

(57) **ABSTRACT**

A field effect transistor (FET) is used as the protection circuit. The gate is grounded through an electrical element. The voltage source is connected to the drain of the FET. The load is connected to the source of the FET. At low input voltages, the FET conducts in body diode mode. At higher input voltages, the FET turns "on" and conducts more efficiently.

10 Claims, 8 Drawing Sheets




Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5




Fig. 6




Fig. 7




Fig. 8




Fig. 9




Fig. 10






Fig. 11



Prior Art

Fig. 12



Prior Art

SYSTEM AND METHOD FOR PROTECTING A LOAD FROM A VOLTAGE SOURCE

BACKGROUND OF THE INVENTION

1. Field of the Invention

The invention relates generally to electronic devices and more particularly to protection circuits for protecting loads from voltage sources.

2. Background

Many electronic devices have electric circuits, known as sensitive circuits, that require protection from certain problematic electrical conditions, such as voltage and power conditions. Common problematic conditions include high voltages (above some threshold), negative voltages and fast changing, negatively moving voltages, also referred to as fast negative transients.

Examples of devices that commonly have circuits that require protection include portable electronic equipment such as, for example, personal digital assistants, laptop computers, and wireless communication devices, including at least cell phones and pagers. Commonly, the sensitive circuits need protection from other circuits to which the sensitive circuits may be connected. For example, AC and DC power sources may present problematic electric conditions to the sensitive circuits. The power source may also be a car power adapter. Another source of problematic electrical conditions is failed AC to DC adapters. Some failed AC to DC adapters may fail such that they present an AC output at the DC side of the adapter.

The numbers and types of electronic devices and their adapters and connections to other electronic devices are growing constantly. It is sometimes troublesome for consumers to be certain that they are connecting the correct connector (e.g., power supply) into their electronic devices. For example, a consumer may have more than one cell phone and more than one charger for each cell phone. The consumer does not want the cell phone to break if the wrong charger is mistakenly plugged into one of the cell phones. Alternately, cell phone manufacturers do not want their cell phones to break if a consumer mistakenly connects the cell phone to the wrong charger. Several companies make cell phone chargers, known as after-market chargers, for other companies' cell phones. The cell phone manufacturers would like to be as certain as possible that the after-market chargers do not break their cell phones, even considering that the after-market chargers may not contain adequate protection circuits.

Some known solutions include connecting the source to the load through a diode, as shown in FIG. 12. The diode 200 is connected to a voltage source 210 and a load 220. The FIG. 12 circuit typically results in poor energy transfer (e.g., charging) efficiency. Diodes have a non-zero forward voltage V_F . They therefore consume energy, lower the voltage available to the load, and produce heat.

Another known solution is shown in FIG. 11. The FIG. 11 circuit also uses a diode 230, but in this case, the diode is connected between ground and the input 240 of the load 220. A fuse 250 is connected between a voltage source 210 and the load 220. A problem with the FIG. 11 circuit is that when an excess current condition occurs, the fuse becomes a permanent open circuit and the source 210 is no longer connected to the load.

Some solutions do not provide for protection from fast negative shoot-through. That is, problems occur if an input voltage drops quickly. Fast negative transients can cause negative shoot through. Negative shoot through happens

when a fast negative transient results in a negative voltage appearing on the load side of a device. For example, a protection circuit may be designed to prevent negative voltages from passing across the protection circuit to a load. A negative shoot through occurs when a transient negative voltage reaches the load due to a fast changing negative input voltage.

SUMMARY OF THE INVENTION

In order to overcome the problems associated with conventional approaches for protecting sensitive electric circuits from problematic electric conditions, a field effect transistor (FET) is used as the protection circuit. The gate is grounded through an electrical element. The voltage source is connected to the drain of the FET. The load is connected to the source of the FET. At low input voltages, the FET conducts in body diode mode. At higher input voltages, the FET turns "on" and conducts more efficiently.

Advantageously, the FET conducts energy from the source to the load more efficiently than some prior solutions.

Other aspects, advantages, and novel features of the invention will become apparent from the following Detailed Description, when considered in conjunction with the accompanying drawings.

BRIEF DESCRIPTION OF THE DRAWINGS

Preferred embodiments of the present inventions taught herein are illustrated by way of example, and not by way of limitation, in the figures of the accompanying drawings, in which:

FIGS. 1–7 show block diagrams illustrating a protection circuit connected to a load and a source voltage.

FIG. 8 shows a graph illustrating a relationship between a gate voltage and a drain to source resistance when a FET is "on".

FIG. 9 shows a graph illustrating a relationship between an input voltage and a gate voltage over time.

FIG. 10 shows a graph illustrating an expanded portion of the gate voltage of FIG. 9, with additional voltages superimposed.

FIGS. 11–12 show block diagrams of prior art protection circuits.

DETAILED DESCRIPTION

FIG. 1 shows a block diagram illustrating a protection circuit 25 connected to a load 30 to be protected from a voltage source 35. The protection circuit has a field effect transistor (FET) 40 connected between the load 30 and the voltage source 35. As will be understood, the source, drain and gate each have conductors or conducting pads, for making electrical connections to other electric components.

The FET may be a metal-oxide semiconductor FET (MOSFET) as is shown in FIG. 1. As is well known in the art, a FET has a gate 45, a source 50 and a drain 55. The drain 55 of the FET 40 is connected to the voltage source 35. The source 50 is connected to the load 30. The gate 45 is connected to an electrical element 60. As shown in FIG. 1, the electrical element 60 may be a resistor 60.

Configured as in FIG. 1, as a positive voltage is applied to the drain 55, from a zero voltage, the MOSFET will first conduct in body diode mode. In body diode mode, the gate to source voltage V_{GS} of a FET is below the threshold $V_{G_{STH}}$ to put the FET in an "on" state, or turn the FET on. In the "on" state, the series resistance of a FET is negligible, but in

body diode mode, the FET has a non-zero forward voltage, which is equivalent to having a non-negligible series resistance. In the body diode mode, the FET acts like a diode from drain to source. Thus, as the input voltage applied to the drain **55** by the voltage source **35** increases from zero, the FET will not conduct until a diode bias voltage of the FET body diode is reached. The diode bias voltage is typically about 0.5 Volts (V)

The voltage at the source **50** will follow and stay lower than the voltage at the drain **55** by about 0.5 V. As the source **50** voltage increases, a voltage develops from the gate to the source, that is, the source **50** is at a higher voltage than the gate **45**, because the gate is grounded. Grounding is shown through resistor **60**. However, the gate may be grounded directly, that is, without the use of resistor **60**. Alternately stated, resistor **60** may have zero resistance.

When the source **50** voltage reaches V_{Gsth} the FET will start to turn on. As will be described later with reference to FIG. **8**, a FET turns on fairly quickly with rising V_{GS} , but it is not an ideal switch with an absolutely abrupt change from on to off. Once the FET is on, the FET conducts from the drain **55** to the source **50**, with a very small series resistance R_{DSON} .

Advantageously, the voltage drop across an "on" FET is much smaller than that across a diode, known as the forward voltage V_F . In other words, the FET acts much more like an ideal switch than a diode, allowing positive voltages to more efficiently pass through the MOSFET and reach the load. The MOSFET consumes less power than a typical diode. This results in less heat generation and more efficient power transfer from the voltage source **35** to the load **30**. Less heat generation can result in several advantages, including avoiding thermal breakdown of devices and avoiding degraded performance due to thermal performance coefficients of various components.

FIG. **2** shows a block diagram of a protection circuit, load and voltage source similar to those shown in FIG. **1**. In addition to the FET **40** and resistor **60**, the protection circuit includes a capacitor **63** connected from the load input **66** to ground. The capacitor **63** serves to store charge to supply positive voltage to protect against any negative voltage that may pass through the other portions of the protection circuit. The capacitor **63** serves, in a sense, as a last line of defense for the load **30** against fast negative transients.

FIG. **3** shows a block diagram illustrating a protection circuit, load and source similar to those in FIG. **2**. Compared to FIG. **2**, an electrical element **69** has been added. The electrical element **69** may be a resistor as shown in FIG. **3**. The resistor **69** overcomes a disadvantage of the circuit shown in FIG. **2**.

The circuit in FIG. **2** does not limit the voltage V_{GS} that can develop across the source and gate. FET's have a breakdown voltage known as the gate to source breakdown voltage, or $V_{GSBreakdown}$. A FET with a higher V_{Gsth} typically has a higher $V_{GSBreakdown}$, and a FET with a lower V_{Gsth} typically has a lower $V_{GSBreakdown}$. For MOSFET's, a typical $V_{GSBreakdown}$ is 12 V for a V_{Gsth} of 2.5 V. Alternatively, a MOSFET with a higher $V_{GSBreakdown}$ of 20 V might have a V_{Gsth} of 5 V. Alternatively a MOSFET with a lower $V_{GSBreakdown}$ of 6 V might have a V_{Gsth} of 1.8 V.

A lower V_{Gsth} is desirable, because a MOSFET with a lower V_{Gsth} typically (1) has better performance, such as a lower R_{DSON} , especially for low gate to source voltages, and (2) allows for operation of the MOSFET at lower source **35** voltages. Lower R_{DSON} , in turn, results in better power transfer from the voltage source **35** to the load **30**. However, a higher $V_{GSBreakdown}$ is also desirable, because voltages

above $V_{GSBreakdown}$ applied across the source **50** and gate **45** result in destruction of the MOSFET. The destruction (failure) mode of a MOSFET is to become an electrical short. Thus, in failure, the MOSFET conducts all the power that destroyed the MOSFET **40** toward the load **30**. This can be catastrophic for the load, especially when and if the power source becomes negative. Therefore, it is important to ensure that V_{GS} never exceeds $V_{GSBREAKDOWN}$.

Resistor **69** has been added in FIG. **3** to reduce the likelihood that V_{GS} will exceed $V_{GSBREAKDOWN}$. Resistor **69** causes the gate **45** voltage to follow the source **50** voltage. Specifically, a positive voltage at the source **50** brings the voltage at the gate **45** up as well. The voltage at the gate V_G is a fraction of the voltage at the source V_S , according to the well known voltage divider function, $V_G = V_S * R1 / (R1 + R2)$, where $R1$ is the resistance of the first resistor **60** and $R2$ is the resistance of the second resistor **69**. Since V_G follows V_S up when V_S goes up, V_{GS} stays smaller. This helps prevent V_{GS} from exceeding $V_{GSBREAKDOWN}$. However, at some higher input voltage from the voltage source **35**, resulting in a higher source **50** voltage, $V_{GSBREAKDOWN}$ can still be exceeded. Furthermore, the circuit of FIG. **3** has the disadvantage that power is consumed by resistor **69** and resistor **60**. The power consumption has the disadvantages of power consumption described above.

Further, the circuit of FIG. **3** has the disadvantage that V_{GS} varies nearly proportionally to the input voltage supplied by the voltage source **35**. As such, at low source **35** voltages, the MOSFET **40** may often operate in a state that is not fully enhanced. Referring to FIG. **8**, a typical MOSFET operating conditions are graphed. The vertical axis **72** shows R_{DSON} , while the horizontal axis **75** shows V_{GS} . As V_{GS} increases from zero V, R_{DSON} goes from a very high resistance to a very low resistance. At a value V_{Gsth} , the MOSFET is considered on, but the MOSFET is not in its more desirable mode of operation until V_{GS} exceeds $V_{ENHANCED}$. R_{DSON} is very low when V_{GS} exceeds $V_{ENHANCED}$. This results in efficient power transfer from the voltage source **35** to the load **30**. Referring again to FIG. **3**, the voltage divider of resistors **60** and **69** cause V_{GS} to change responsive to the input voltage, and possibly go below $V_{ENHANCED}$, causing inefficient power transfer.

The FIG. **4** circuit has several advantages over the FIG. **3** circuit. In FIG. **4**, the resistor **69** has been replaced with a different electrical element **80**. The electrical element **80** is a zener diode **80**. For purposes of this specification and the appended claims, an electrical element is any element that can conduct electricity. The following is a non-exhaustive list of examples of electrical elements: resistors, capacitors, inductors, diodes, zener diodes, transistors, integrated circuit portions such as CMOS connecting lines and vias and integrated capacitors, inductors and resistors, and any combination of components including one or more electrical elements.

The zener diode **80** primarily operates to keep V_{GS} nearly constant as long as the input voltage V_{IN} supplied by the voltage source **35** is above $V_Z + V_{RDSON}$, where V_Z is the zener diode turn on voltage and V_{RDSON} is the very small voltage drop from the drain to the source of the MOSFET when the MOSFET is on. As is well known in the art, zener diodes have a nearly constant voltage once they are on. Thus, once the zener diode **80** is on, it holds V_{GS} to a nearly constant value. With careful selection of the zener diode turn on voltage to correspond to a voltage above $V_{ENHANCED}$, but below $V_{GSBREAKDOWN}$, it can be ensured that V_{GS}

5

is not exceeded, and that the electrical element **80** does not limit gate to source voltage of the MOSFET while V_S is below V_Z .

Using a zener diode **80** especially improves the performance of the MOSFET, improving power transfer efficiency, when V_{IN} is less than $V_Z + V_{R_{DS(on)}}$, because then the zener diode **80** is practically like an open circuit. That increases V_{GS} over the FIG. 3 circuit, for low input (source **35**) voltages.

But the FIG. 4 circuit does have some drawbacks. First, zener diodes are relatively expensive compared to some transistors and other diodes. Second, a zener diode with a lower zener voltage is generally preferred for use with a MOSFET **40** with a lower $V_{ENHANCED}$ and therefore a lower $V_{R_{DS(on)}}$. However, zener diodes with low zener voltages, and therefore compatible with low $V_{G_{STH}}$ MOSFET's typically have poor temperature coefficients, higher leakage current and less sharp knees, compared to zener diodes with higher zener voltages. A poor temperature coefficient means that the performance characteristics change more with temperature. More leakage means that in the off state, that is, at voltages below the zener voltage, more current still leaks through the zener diode. This would raise the gate voltage, which would decrease V_{GS} , which would increase $R_{DS(on)}$, which would result in decreased power transfer efficiency. Having a less sharp knee means that a lower zener voltage zener diode turns on more gradually as the voltage across the zener diode increases.

The FIG. 5 circuit has several advantages over the FIG. 4 circuit. In FIG. 5, the zener diode has been replaced with a transistor **77** and two resistors **79** and **81**. The transistor **77** has a collector **83**, an emitter **85** and a base **88**. The collector **83** is connected to source **50**. The emitter is connected to the resistors **60** and **81**. The base **88** is connected to the resistors **79** and **81**. The resistor **79** is connected between the source **50** and the base **88**. The resistor **81** is connected between the base **88** and the emitter **85**.

Thus, the transistor **77** is configured as a programmable zener from collector to emitter. In other words, V_{CE} acts as the zener voltage. V_{CE} is controlled, or selected, by selecting the resistors **79** and **81** which act as a voltage divider to control V_{CE} and V_{BE} .

Advantageously, the transistor is cheaper than a typical zener diode, and offers better performance in terms of leakage current, temperature coefficient and operating current.

Even with all the protection provided as discussed with reference to FIGS. 1-5, there may still be a problem with a negative voltage passing through the protection circuit from the voltage source **35** under certain conditions. Specifically, negative shoot through may be a problem. Negative shoot through is the result of fast changes from some voltage to a more negative voltage. This causes the parasitic capacitances of the MOSFET to send transient negative voltages through the protection circuit to the load to be protected **30**. The protection circuit protects from slowly changing voltages, but fast transients created by fast negative changes may get through and damage the load **30**. As will be understood by those of skill in the art, fast transients can be in part due to parasitic capacitance between the MOSFET gate and source, between the MOSFET source and drain, and between the MOSFET drain and gate.

The FIG. 6 circuit has some advantages over the FIG. 5 circuit. In the FIG. 6 circuit, a diode **92** has been added, connected between ground and the gate **45** of the FET **40**, with the forward bias direction of the diode **92** being from ground to the gate **40**. The diode provides protection against

6

negative shoot through. Specifically, the diode limits the gate voltage V_G to be no lower than one forward bias voltage of the diode **92** below zero, or ground. That is, V_G is always greater than or equal to $-V_F$, where V_F is the forward bias voltage of the diode **92**. Since the gate voltage can go no lower than $-V_F$, that means the source **50** can go no lower than $V_{G_{STH}} - V_F$, while the FET is in the "on" state. Through careful selection of $V_{G_{STH}}$ and V_F , it can be assured that $V_{G_{STH}}$ is greater than V_F , so that V_S is never below zero, or ground. Since the voltage at the load **30** is essentially equal to V_S , the voltage at the load **30** is never below zero, or ground.

The operation of the diode **92** within the protection circuit will now be described with respect to FIGS. 9 and 10. Referring to FIG. 9, a fast negative changing input voltage V_{IN} is shown as input voltage line **96**. V_{IN} is an example input voltage provided by voltage source **35**. V_{IN} is plotted against the horizontal axis **100** of time. V_{IN} has a fast negative changing portion **104**. The negative changing portion **104** is shown as a vertical line. It will be understood that vertical portion **104** is an ideal representation of a fast negative changing voltage, whereas real physical quantities are not ideal. The ideal fast negative changing portion **104** is shown to make the point that the negative change occurs fast enough to cause a problem for the protection circuit without the diode **92**.

V_G is also plotted against time in FIG. 9. Even though the FET **40** turns off as V_{IN} drops below zero V, the parasitic capacitance of the FET allows V_G to briefly drop below zero as shown by dip **112**. If not accounted for and corrected in the protection circuit, the dip **112** below zero volts can cause a transient negative voltage to appear at the load **30**, possibly causing damage. An expanded view of a portion of FIG. 9 designated by circle **114** is shown in FIG. 10.

FIG. 10 shows the voltage response of the protection circuit with a fixed forward voltage device, such as diode **92**, protection diode **92** is superimposed on voltage response of the protection circuit without a fixed forward voltage device, such as diode **92**, both in negative shoot through conditions. FIG. 10 is a graph of voltage on the vertical axis (not shown) against time on the horizontal axis **118**. Several different voltages are shown in FIG. 10. A $V_{G_{UNP}}$ is shown as line **108**, where $V_{G_{UNP}}$ refers to V_G unprotected, that is, the gate **45** voltage as a result of negative shoot through without a fixed forward voltage device, such as diode **92**, protecting against negative shoot through. In other words, $V_{G_{UNP}}$ **108** represents the gate **45** voltage that could occur without protection diode **92**.

A $V_{S_{UNP}}$ line **116** shows the source **50** voltage that may occur without protection diode **92**. $V_{S_{UNP}}$ **116** is at least $V_{G_{STH}}$ above $V_{G_{UNP}}$, because the minimum difference in voltage between the gate **45** and the source **50** is $V_{G_{STH}}$, as is shown by arrow **120**. Since voltage line **116** shows the voltage at the source **50**, it is representative of the negative voltage that could damage load **30** in cases of negative shoot through.

The addition of protection diode **92** changes the various voltages present at various points in the circuit during negative shoot through conditions. As described above, the diode **92** is connected to ground, which keeps one end of the diode at zero V, or ground. When negative shoot through conditions occur, the cathode of the diode can go no lower than $-V_F$, because the diode **92** has a constant forward voltage (or zero forward voltage). V_G is limited by the diode **92** to no less than $-V_F$, as shown by dashed line **124**. V_S is at least $V_{G_{STH}}$ above V_G , as shown by arrow **132**. Thus, advantageously, V_S can be restricted to positive voltages,

even in cases of negative shoot through, as long as V_{GSTH} is greater than V_F . The load **30** is protected even in cases of negative shoot through.

With a diode **92** connected between ground and the gate of the FET **40**, the negative shoot through protection will be limited only by the resistance connected to the gate **45**, the parasitic capacitances present, the capacitance of the capacitor **63** and the negative recovery time of the diode. In some cases, it may be advantageous to use a majority carrier diode, such as a Schottky diode for diode **92**. Schottky diodes have a negligible reverse recovery time, because they are majority carrier diodes. As such, a Schottky diode will protect against negative shoot through even better than a normal diode.

The FIG. **7** circuit has some advantages over the FIG. **6** circuit. As shown in FIG. **7**, a transistor **135** replaces the diode **92**. As is well known in the art, the transistor has a base **145**, a collector **150** and an emitter **155**. The base **145** is connected to ground. The collector is connected to the gate **45** of the FET **40**. The emitter **155** is connected to ground. In this way, the transistor **135** is configured as a diode, from collector to base. This is not the common way to configure an npn bipolar junction (BPJ) transistor as a diode though. Traditionally, or commonly, an npn BPJ transistor is configured as a diode from base to emitter, as is well known in the art. Configuring the transistor as a diode from collector to base typically produces the advantage that the resulting diode has a higher reverse bias limit than a diode resulting from a transistor configured as a diode from base to emitter.

Advantageously, the third transistor **135** can be part of a single integrated circuit package with the second transistor **77**. Commercially, transistors are commonly available in two-transistor packages. Thus, replacing diode **92** with transistor **135** may reduce the cost of the protection circuit.

In one configuration, resistor **79** may have a resistance of 56K ohms. Resistor **81** may have a resistance of 10K ohms. Resistor **60** may have a resistance of 2K ohms. Capacitor **63** may have a capacitance of 2.2 microfarads. However, it will become clear to one of skill in the art that many values of the above-mentioned components are possible. Further, a single design can work for a broad range of component values. For example, resistor **79** may have a resistance of 65K ohms and still contribute to effective operation of the protection circuit. As another example, resistor **60** may have a resistance of 10K ohms and still contribute to effective operation of the protection circuit. Further, FET **40** may be a commercially available FDC6036 MOSFET. Transistors **77** and **135** may be situated together in a Rohm EMX2 or UMX2N transistor package.

Various combinations of the circuits shown in FIGS. **1-7** are possible. For example, FIGS. **4** and **6** could be combined to produce a protection circuit having a zener diode **80** connected between the gate **45** and the drain **50** of the FET **40**, while having a diode **92** connected between the zener diode **80** and ground. Such a protection circuit would have the advantages of the FIG. **4** circuit and some of the advantages of the FIG. **6** circuit, but not all of the advantages of the FIG. **6** circuit.

Commonly the load and the voltage source are contained in two different devices. The protection circuits described above may be integrated in the device containing the load, the device containing the voltage source, a single device containing both the load and the source, or a separate protection device altogether. Additionally, some of the protection circuit may be in one device while another part of the protection circuit may be in another device, so long as the components can be connected as described when the devices

are connected together. For example, the capacitor **63** may be contained in the electronic device containing the load **30**, while the FET **40** is contained in the electronic device containing the remainder of the protection circuit.

It will be understood that while the protection circuit has been described with a p-channel FET **40**, FET **40** could be replaced with an n-channel FET (not shown), reversing the polarity of the protection circuit. Such a protection circuit could be used in conjunction with a source and load having a positive ground. In that case, the source and load voltages would be negative in normal operation and the protection circuit would protect against at least one of the following: positive voltages, high absolute valued negative voltages, and fast changing positive moving voltages. The drain of the n-channel FET would be connected to the voltage source **35**. The source of the n-channel FET would be connected to the load **30**.

An advantage of using an n-channel FET is that the performance of n-channel FET's is generally better than that of p-channel FET's, because n-channel FET technology is more mature than that of p-channel FET technology. An advantage of using a p-channel FET is that a p-channel FET works in a protection circuit with a negative ground. This is particularly useful in devices having other circuits with a negative ground. For example, in a wireless communication device, RF circuits typically use a negative ground. Thus, it is advantageous if the DC circuits, such as power supplies and charging circuits, use a negative ground.

The other circuit elements shown in FIGS. **1-7**, would be configured the same as in FIGS. **1-7**, except that the polarities of the active elements (diodes, zener diodes and transistors), if present, would be reversed. For example, if an n-channel FET were used, a zener diode, in a similar configuration to that shown in FIG. **4**, would be connected between the n-channel FET source and the n-channel FET gate.

Further, while embodiments and implementations of the invention have been shown and described, it should be apparent that many more embodiments and implementations are within the scope of the invention. Accordingly, the invention is not to be restricted, except in light of the claims and their equivalents.

What is claimed is:

1. A protection circuit for protecting a load from a voltage source, the protection circuit comprising:
 - a field effect transistor (FET) having a drain, a source and a gate
 - a load output conductor connectable to the source;
 - a voltage source input conductor connectable to the drain;
 - a first electrical element connected to the gate and to an electrical ground;
 - a second transistor having a first collector, a first base, and a first emitter where the first collector is connected to the FET's source and the first emitter is connected to the FET's gate.
2. The protection circuit of claim **1**, further comprising:
 - a resistor connected between the gate of the FET and the first base; and
 - a second resistor connected between the first base and the first collector.
3. The protection circuit of claim **1**, further comprising a second electrical element connected between the gate and the electrical ground.
4. The protection circuit of claim **3**, wherein the second electrical element comprises a third transistor, the third transistor having a second collector, second base, and second emitter.

9

5. The protection circuit of claim 4, further comprising an electrical conductor electrically connecting the second emitter and the second base, and where the second collector is connected to the first emitter.

6. A method of protecting a circuit from a voltage source, 5
the method comprising:
providing a field effect transistor (FET), FET having a drain, a source and a gate;
providing a connection between the drain of the FET to a conductor for coupling to the voltage source; 10
providing a connection between the source of the FET to a conductor for coupling to the circuit;
providing a connection between the gate to a first electrical element;
providing a connection between the first electrical element to an electrical ground; and 15
providing a second transistor having a first collector, a first base, and a first emitter where the first collector is connected to the FET's source and the first emitter is connected to the FET's gate.

10

7. The method of claim 6, further comprising:
having a connection between the gate of the FET and the first base through a first resistor; and

having a connection between the first base and the first collector through a second resistor.

8. The method of claim 6 further comprising
providing a second electrical element between the gate and the electrical ground.

9. The method of claim 8, wherein the second electrical element comprises a third transistor, the third transistor having a second collector, second base, and second emitter.

10. The method of claim 9, further comprising providing a connection between the second emitter and the second base and a connection between the second collector is connected to the first emitter.

* * * * *